

Transport of the deceased...

What is an Escape-Mattress® Mortipod?

The Escape-Mattress® Mortipod is a mobility solution for the undertakers. A deceased passing through narrow corridors and stairs from top to bottom is a heavy physical load. It is physically demanding work. The Mortipod makes it easier to transport the deceased horizontally or over the stairs, with minimal impact on your back.

How does an Escape-Mattress® Mortipod work?

The Escape-Mattress® Mortipod replaces the existing mattress. With the towing straps and side handles, it can be used directly as a drag and carry mattress. The big advantage is that the Mortipod is ready to be placed on the stretcher, ready for transport without an extra transfer.

Advantages Escape-Mattress® Mortipod:

- Safe and ergonomic on the stairs.
- Due to its narrow design, the Mortipod is very viable and therefore easier for use in narrow spaces.
- Handgrips to assist with sideways manoeuvrability.
- Ready for use within seconds.
- Extra-long towing straps to help operators with improved handling practices.
- Glides safely down stairs
- Carrying the deceased is no longer necessary.
- Easy manoeuvrability.
- Easy to clean (no Velcro used - hygiene).
- Speed of descent is determined by the user.
- TÜV & CE certified.

Our advice:

Ensure your carriage is equipped with an Escape-Mattress® Mortipod. Make it easy for a professional undertaker to save as much time, costs, and space as possible.





Specifications:	Escape-Mattress® Mortipod	CE
Article number Mortipod (without storage bag):	21050	
Article number storage bag:	21051	
Article number extra body bag:	21052	
Article number extra head rest:	21053	
Dimensions (length x width x thickness):	ca. 180 x 47 x 8 cm	
Maximum payload:	150 kg	
Weight:	ca. 7,2 kg	
Warranty:	2 years	
Free demonstration and advise provided:	✓	
Ready to use within seconds:	✓	
Speed of descent to be determined by the user:	✓	
3 in 1 solution for the undertakers / coroners:	✓	
Body bag detachable for easier cleaning:	✓	
Can be cleaned with disinfectant:	✓	
Compact and easy to store	✓	
Separate user manual available:	✓	
Color:	Mouse gray	



Interim changes to technical specifications and printing errors reserved.
Produced by Escape Mobility Production & Innovation: TÜV approved organization.



Escape Mobility International BV

Bocholtzweg 14C • NL-6369 TG • Simpelveld • The Netherlands
T +31 (0)45 528 06 70
info@escape-mobility.com
www.escape-mobility.com