



Escape-Chair CF



Evacuation ascending the stairs, while in a seated position.

What's an Escape-Chair CF?

An **Escape-Chair CF** is the solution to evacuate people to safety in a seated position down a flight of stairs. A simple procedure can make the **Escape-Chair CF** fully functional within a few seconds.

How does an Escape-Chair work?

The unique glide/brake system makes the braking of the **Escape-Chair CF** possible on all different kinds of stairs, from wood to concrete. This braking system is optimized by the weight of the evacuee, in combination with the pressure of the operator pushing down on the handle in the direction of the stairs.

Advantages of the Escape-Chair CF:

- Ideal for quick evacuation.
- Can be operated by a single person.
- Ready for use within seconds.
- Carrying people is no longer necessary.
- Speed of descent to be determined by the user (extra brake is unnecessary).
- Easily maneuvering into the evacuation flow.
- Forms minimal blockage on the stairs.
- Fits into your emergency plan.
- Safe closed gliding belt cassette.
- CE, TÜV NORD & ISO certified.

Specifications	Escape-Carry Chair CF
Article number:	10040
Dimensions folded up (height x width x depth):	116 x 57 x 21 cm
Maximum payload:	225 kg
Maximum stair gradient:	45°
Weight:	± 15 kg
Ergonomic backrest:	double
Ready for use within seconds:	✓
Speed of descent to be determined by the user:	✓
Safe closed gliding belt cassette:	✓
Reflective strips:	✓
CE, TÜV NORD & ISO certified:	✓
Delivery included:	✓
5-language manual:	✓
Photoluminescent identity sign:	✓
Wall hooks:	✓
Flame retardant dust cover:	✓
Footrest:	✓
Armrests:	✓
Padded (upholstered) headrest:	✓
Flame retardant comfort seat:	✓
Two height adjustable operating handles:	✓
Warranty on non-wearing parts:	10 years

Our advice:

Make sure you have an **Escape-Chair CF** available in your organisation so that you're prepared for any emergency, for up and/or down evacuation.

"Failure to prepare for an emergency has its consequences."



E: info@escape-mobility.com

Escape Mobility Company Ltd.
85 Great Portland Street, 1st floor,
London, W1W 7LT

T: +44 (0)1908 229 028

W: www.escape-mobility.com

Escape Mobility International BV.
Jan Campertstraat 7 – Unit 1.14,
6416 SG, Heerlen.

T: +31 (0)45 528 0670

...your way to safety

